


Switch Box User Manual

Keep this card for instructions or new Configurations.



For simple switching between a Handset and a Headset.


Connect as per the diagram above. The headset must be connected on the "Headset" output and the handset also on the "Handset" output. The mute button cuts off the microphone. Push the switch again to resume communication with your caller.

Notes:


This device has been set to the most common configuration. However, your telephone may be different and require a different setting to be compatible.

To change connection settings:

- (1) Slide the compatibility switch located on the side of the device until it can be properly adjusted.



- (2) The position of polarity switch is on the right side before factory release as below drawing. To adjust proper polarity switch, make a phone call to your friend and adjust slide switch to the left & right by turns until he can hear your voice more loudly and clearly.



※Notice : If you do not properly set the polarity position, the sensitivity of headset microphone will be decreased and dead easily.

- (3) If you are still experiencing difficulties, the headset configuration may be incorrect or incompatible with this device.